

Correct Speaker Wiring Polarity For The Axium AX800 / 400 Amplifiers, one zone shown.



Incorrect Speaker Wiring, -v cannot be swapped.



A Standard Class AB amplifier may work in this mode as the –v terminals are normally joined internally

